

## ADMONTER IN BATHROOMS

### FLOORs

**All Admonter wide-plank floors, except European Beech, are suitable for use in bathrooms under the following conditions:**

- Installation with a full-surface stick down using Admonter Elastic adhesive or a similar product.
- A natural oil finish .
- The application of Maintenance Oil post installation (additional oil coat) and re-oiling when necessary.
- Use of silicon or similar product to close expansion gaps between the floor and walls.
- Avoid standing water on the floor. Ensure spilt water is immediately dried with a clean and dry soft cloth to avoid water stains occurring.

### ELEMENTs

- When cladding walls or ceilings with Admonter products, it is important to ensure a permanent air gap is maintained behind the product to enable sufficient air circulation. This could be achieved using a batten system to adhere the Admonter product to.
- To avoid condensation build-up on cool walls, sufficient insulation must be provided behind the air gap – see point above.

### FLOORs and ELEMENTs

- Always test bath salts and shower gels on the floor before use to avoid stains or marks occurring.
- Ensure that the average room climate complies with the installation and maintenance instructions. Also refer to our “Indoor Climate Chart”.
- **DO NOT USE ADMONTER FLOORS AND PANELS IN THE SHOWER AREA.**
- Waterproofing and membrane installation should be as per the Architects details and requirements.
- Please follow the Installation and Cleaning & Maintenance instructions.

October 2017

**Admonter**  
Holzindustrie AG

8911 Admont / Austria, Sägestraße 539

phone: +43(0)3613/3350-0, fax: +43(0)3613/3350-119, e-mail: info@admonter.at

FN237499p (LG Leoben) Gerichtsstand Liezen, UID-Nr.: ATU57198366

Bankverbindung: Raiffeisenbank Admont, IBAN: AT88 3800 1000 0002 7276, BIC: RZSTAT2G001

